


FX4 Semi-Automatic Shotgun General Assembly




FX4 Semi-Automatic Shotgun General Assembly Part List

Stock No.	Description
KB00	Trigger Group Assembly
KG01	Recoil Spring Tube
KG03	Recoil Spring
KG04	Recoil Spring Cap
KG05	Carrier Latch Pin
KG06	Carrier Latch
KG07	Carrier Latch Spring
KG08	Carrier Latch Button Pin
KG09	Carrier Latch Button Spring
KG10	Carrier Latch Button
KG11	Fore End Latch
KG12	Fore End Latch Screw
KG13	Magazine Long Spring Cup
KG14	Magazine Spring
KG15	Magazine Short Spring Cup
KG16	Magazine Plug
KG17	Magazine Tube
KG18	Magazine Plug blocker
KG19	Action Bar
KA01	Walnut Stock
KSA01	Synthetic Stock
KA03	Rubber Recoil Pad
KA04	Rubber Recoil Pad Screw
KA07	Fore End Blocker Spring
KA08	Fore End Blocker
KA09	Fore End Blocker Screw
KA10	Walnut Fore End
KSA10	Synthetic Fore End
KA11	Fore End Nut
KA12	Fore End Pinned Plate
KA13	Fore End Plate
KN01	Barrel

KN02	Front Sight
KN07	Gas Hole O-Ring
KN09	Choke Tube
KN10	Gas Hole Joint
KN11	Gas Hole Plug
KS05	Piston
KS06	Piston O-Ring
KS07	Piston Ring

FX4 Semi-Automatic Shotgun Trigger Group Assembly – B00



FX4 Semi-Automatic Shotgun Trigger Group Assembly Part List

Stock No.	Description
KB01	Trigger Guard
KB02	Hand Safety
KB03	Safety Plunger Spring Pin
KB04	Safety Plunger Spring
KB05	Safety Spring Retaining Pin
KB06	Trigger Fixing Pin
KB07	Disconnecter
KB09	Trigger Spring
KB10	Trigger
KB11	Hammer Drop Spring
KB12	Hammer Drop Part
KB13	Hammer Drop Pin
KB14	Trigger Pin
KB15	Hammer
KB16	Hammer Spring
KB17	Hammer Spring Cap
KB18	Hammer Latch Spindle
KB19	Hammer Latch
KB20	Hammer Tube Pin
KB21	Hammer Tube Piston Ring
KB22	Trigger Guard Latch Spring
KB23	Trigger Guard Latch Spring
KB24	Carrier
KB25	Breech Bolt Latch
KB26	Breech Bolt Latch Pin
KB27	Carrier Pin
KB28	Carrier Spring
KB29	Carrier Spring Pin
KB30	Receiver Pin

FX4 Semi-Automatic Shotgun Bolt Group Assembly – KM00

